

TYPE RL-C
INSTALLATION
INSTRUCTIONS

FILE 58

READ AND UNDERSTAND INSTRUCTIONS BEFORE PROCEEDING WITH WORK.

1. BLOCK UP MACHINE to proper operating position. Check for 1" floor clearance and level for equipment with spring isolators.
2. POSITION RL-C HOUSING locate anchor holes 3" from machine frame, center square tubes. Check for 1/4" clearance between tubes and mark position.
3. TACK WELD SMALL TUBES to machine frame. Check for horizontal with spirit level. Weld tubes in place.
4. RETURN HOUSINGS, mark and drill anchor bolt locations and anchor housings in place.
5. BOLT END PLATE as shown.
6. ADJUST ISOLATORS until blocks can be removed.

