


TYPE RH & RHD

HANGER INSTALLATION INSTRUCTIONS

FILE 43



1. Mount hanger box directly against structural element.
Do not support hanger from slab diaphragms.
2. Attach lower hanger rod to Neoprene element end and equipment.
3. Turn nut on lower hanger rod until load is transferred to Neoprene element.
4. Adjust lower nut to level equipment.

NOTE : Upper and lower hanger rods, nuts and washers by others.